


# Piastre rettificate Finished flat steel plates



## R0288

Piastra rettificata - P2842R  
Finished flat steel plate - P2842R



Colore identificativo  
Colour symbol

### Descrizione:

**Esempio di ordinativo: R0288-06-0001**

Materiale: 1.2842

Tolleranze L500: S +0.05 mm, B +0.2 mm, L +5 mm;

Tolleranze L1030: S +0.05 mm, B +0.2 mm, L + 35 mm;

Per la sezione quadrata: S e B +0.05 mm

### Description:

**Example of purchasing order: R0288-06-0001**

Material: 1.2842

Tolerances L500: S +0.05 mm, B +0.2 mm, L +5 mm;

Tolerances L1030: S +0.05 mm, B +0.2 mm, L + 35 mm;

For square section: S and B +0.05 mm


| Codice<br>Code | L   | B   | S    |      |      |      |      |      |      |      |      |      |      |      |      |      |      |      |      |      |      |
|----------------|-----|-----|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|
|                |     |     | 1    | 1.5  | 2    | 3    | 4    | 5    | 6    | 8    | 10   | 12   | 15   | 16   | 18   | 20   | 25   | 30   | 40   | 50   | 60   |
| R0288-06       | 500 | 4   |      |      |      |      | 0001 |      |      |      |      |      |      |      |      |      |      |      |      |      |      |
| R0288-06       | 500 | 5   |      |      |      |      |      | 0003 |      |      |      |      |      |      |      |      |      |      |      |      |      |
| R0288-06       | 500 | 6   |      |      |      |      |      |      | 0005 |      |      |      |      |      |      |      |      |      |      |      |      |
| R0288-06       | 500 | 8   |      |      |      |      |      |      |      | 0007 |      |      |      |      |      |      |      |      |      |      |      |
| R0288-06       | 500 | 10  | 0009 | 0010 | 0011 | 0013 | 0015 | 0017 | 0019 | 0021 | 0023 |      |      |      |      |      |      |      |      |      |      |
| R0288-06       | 500 | 12  | 0025 | 0026 | 0027 | 0029 | 0031 | 0033 | 0035 | 0037 | 0039 | 0041 |      |      |      |      |      |      |      |      |      |
| R0288-06       | 500 | 15  | 0043 | 0044 | 0045 | 0047 | 0049 | 0051 | 0053 | 0055 | 0057 | 0059 | 0061 |      |      |      |      |      |      |      |      |
| R0288-06       | 500 | 16  |      |      |      |      |      |      |      |      |      |      |      | 0063 |      |      |      |      |      |      |      |
| R0288-06       | 500 | 18  |      |      |      |      |      |      |      |      |      |      |      |      | 0065 |      |      |      |      |      |      |
| R0288-06       | 500 | 20  | 0067 | 0068 | 0069 | 0071 | 0073 | 0075 | 0077 | 0079 | 0081 | 0083 | 0085 |      |      | 0087 |      |      |      |      |      |
| R0288-06       | 500 | 25  | 0089 | 0090 | 0091 | 0093 | 0095 | 0097 | 0099 | 0101 | 0103 | 0105 | 0107 |      |      | 0109 | 0111 |      |      |      |      |
| R0288-06       | 500 | 30  | 0113 | 0114 | 0115 | 0117 | 0119 | 0121 | 0123 | 0125 | 0127 | 0129 | 0131 |      |      | 0133 | 0135 | 0137 |      |      |      |
| R0288-06       | 500 | 35  | 0139 | 0140 | 0141 | 0143 | 0145 | 0147 | 0149 | 0151 | 0153 | 0155 | 0157 |      |      | 0159 | 0161 | 0163 |      |      |      |
| R0288-06       | 500 | 40  | 0165 | 0166 | 0167 | 0169 | 0171 | 0173 | 0175 | 0177 | 0179 | 0181 | 0183 |      |      | 0185 | 0187 | 0189 | 0191 |      |      |
| R0288-06       | 500 | 50  | 0193 | 0194 | 0195 | 0197 | 0199 | 0201 | 0203 | 0205 | 0207 | 0209 | 0211 |      |      | 0213 | 0215 | 0217 | 0219 | 0221 |      |
| R0288-06       | 500 | 60  | 0223 | 0224 | 0225 | 0227 | 0229 | 0231 | 0233 | 0235 | 0237 | 0239 | 0241 |      |      | 0243 | 0245 | 0247 | 0249 | 0251 | 0253 |
| R0288-06       | 500 | 70  | 0255 | 0256 | 0257 | 0259 | 0261 | 0263 | 0265 | 0267 | 0269 | 0271 | 0273 |      |      | 0275 | 0277 | 0279 | 0281 | 0283 |      |
| R0288-06       | 500 | 80  | 0285 | 0286 | 0287 | 0289 | 0291 | 0293 | 0295 | 0297 | 0299 | 0301 | 0303 |      |      | 0305 | 0307 | 0309 | 0311 | 0313 |      |
| R0288-06       | 500 | 100 | 0315 | 0316 | 0317 | 0319 | 0321 | 0323 | 0325 | 0327 | 0329 | 0331 | 0333 |      |      | 0335 | 0337 | 0339 | 0341 | 0343 |      |
| R0288-06       | 500 | 120 | 0345 | 0346 | 0347 | 0349 | 0351 | 0353 | 0355 | 0357 | 0359 | 0361 | 0363 |      |      | 0365 | 0367 | 0369 | 0371 | 0373 |      |
| R0288-06       | 500 | 125 | 0375 | 0376 | 0377 | 0379 | 0381 | 0383 | 0384 | 0387 | 0389 | 0391 | 0393 |      |      | 0395 | 0397 | 0399 | 0401 | 0403 |      |
| R0288-06       | 500 | 150 | 0405 | 0406 | 0407 | 0409 | 0411 | 0413 | 0415 | 0417 | 0419 | 0421 | 0423 |      |      | 0425 | 0427 | 0429 | 0431 | 0433 |      |
| R0288-06       | 500 | 160 | 0435 | 0436 | 0437 | 0439 | 0441 | 0443 | 0445 | 0447 | 0449 | 0451 | 0453 |      |      | 0455 | 0457 | 0459 | 0461 | 0463 |      |
| R0288-06       | 500 | 180 | 0465 | 0466 | 0467 | 0469 | 0471 | 0473 | 0475 | 0477 | 0479 | 0481 | 0483 |      |      | 0485 | 0487 | 0489 | 0491 | 0493 |      |
| R0288-06       | 500 | 200 | 0495 | 0496 | 0497 | 0499 | 0501 | 0503 | 0505 | 0507 | 0509 | 0511 | 0513 |      |      | 0515 | 0517 | 0519 | 0521 | 0523 |      |
| R0288-06       | 500 | 250 | 0525 | 0526 | 0527 | 0529 | 0531 | 0533 | 0535 | 0537 | 0539 | 0541 | 0543 |      |      | 0545 | 0547 | 0549 | 0551 | 0553 |      |
| R0288-06       | 500 | 300 | 0555 | 0556 | 0557 | 0559 | 0561 | 0563 | 0565 | 0567 | 0569 | 0571 | 0573 |      |      | 0575 | 0577 | 0579 | 0581 | 0583 |      |

# Piastre rettificate Finished flat steel plates



## R0288

Piastra rettificata - P2842R  
Finished flat steel plate - P2842R



Colore identificativo  
Colour symbol

### Descrizione:

Esempio di ordinativo: **R0288-06-0001**

Materiale: 1.2842

Tolleranze L500: S +0.05 mm, B +0.2 mm, L +5 mm;

Tolleranze L1030: S +0.05 mm, B +0.2 mm, L + 35 mm;

Per la sezione quadrata: S e B +0.05 mm

### Description:

Example of purchasing order: **R0288-06-0001**

Material: 1.2842

Tolerances L500: S +0.05 mm, B +0.2 mm, L +5 mm;

Tolerances L1030: S +0.05 mm, B +0.2 mm, L + 35 mm;

For square section: S and B +0.05 mm

| Codice<br>Code | L    | B   | S |     |      |      |      |      |      |      |      |      |      |      |      |      |      |      |
|----------------|------|-----|---|-----|------|------|------|------|------|------|------|------|------|------|------|------|------|------|
|                |      |     | 1 | 1.5 | 2    | 3    | 4    | 5    | 6    | 8    | 10   | 12   | 15   | 16   | 18   | 20   | 25   | 30   |
| R0288-06       | 1000 | 4   |   |     |      |      | 0002 |      |      |      |      |      |      |      |      |      |      |      |
| R0288-06       | 1000 | 5   |   |     |      |      |      | 0004 |      |      |      |      |      |      |      |      |      |      |
| R0288-06       | 1000 | 6   |   |     |      |      |      |      | 0006 |      |      |      |      |      |      |      |      |      |
| R0288-06       | 1000 | 8   |   |     |      |      |      |      |      | 0008 |      |      |      |      |      |      |      |      |
| R0288-06       | 1000 | 10  |   |     | 0012 | 0014 | 0016 | 0018 | 0020 | 0022 | 0024 |      |      |      |      |      |      |      |
| R0288-06       | 1000 | 12  |   |     | 0028 | 0030 | 0032 | 0034 | 0036 | 0038 | 0040 | 0042 |      |      |      |      |      |      |
| R0288-06       | 1000 | 15  |   |     | 0046 | 0048 | 0050 | 0052 | 0054 | 0056 | 0058 | 0060 | 0062 |      |      |      |      |      |
| R0288-06       | 1000 | 16  |   |     |      |      |      |      |      |      |      |      |      | 0064 |      |      |      |      |
| R0288-06       | 1000 | 18  |   |     |      |      |      |      |      |      |      |      |      |      | 0066 |      |      |      |
| R0288-06       | 1000 | 20  |   |     | 0070 | 0072 | 0074 | 0076 | 0078 | 0080 | 0082 | 0084 | 0086 |      |      | 0088 |      |      |
| R0288-06       | 1000 | 25  |   |     | 0092 | 0094 | 0096 | 0098 | 0100 | 0102 | 0104 | 0106 | 0108 |      |      | 0110 | 0112 |      |
| R0288-06       | 1000 | 30  |   |     | 0116 | 0118 | 0120 | 0122 | 0124 | 0126 | 0128 | 0130 | 0132 |      |      | 0134 | 0136 | 0138 |
| R0288-06       | 1000 | 35  |   |     | 0142 | 0144 | 0146 | 0148 | 0150 | 0152 | 0154 | 0156 | 0158 |      |      | 0160 | 0162 | 0164 |
| R0288-06       | 1000 | 40  |   |     | 0168 | 0170 | 0172 | 0174 | 0176 | 0178 | 0180 | 0182 | 0184 |      |      | 0186 | 0188 | 0190 |
| R0288-06       | 1000 | 50  |   |     | 0196 | 0198 | 0200 | 0202 | 0204 | 0206 | 0208 | 0210 | 0212 |      |      | 0214 | 0216 | 0218 |
| R0288-06       | 1000 | 60  |   |     | 0226 | 0228 | 0230 | 0232 | 0234 | 0236 | 0238 | 0240 | 0242 |      |      | 0244 | 0246 | 0248 |
| R0288-06       | 1000 | 70  |   |     | 0258 | 0260 | 0262 | 0264 | 0266 | 0268 | 0270 | 0272 | 0274 |      |      | 0276 | 0278 | 0280 |
| R0288-06       | 1000 | 80  |   |     | 0288 | 0290 | 0292 | 0294 | 0296 | 0298 | 0300 | 0302 | 0304 |      |      | 0306 | 0308 | 0310 |
| R0288-06       | 1000 | 100 |   |     | 0318 | 0320 | 0322 | 0324 | 0326 | 0328 | 0330 | 0332 | 0334 |      |      | 0336 | 0338 | 0340 |
| R0288-06       | 1000 | 120 |   |     | 0348 | 0350 | 0352 | 0354 | 0356 | 0358 | 0360 | 0362 | 0364 |      |      | 0366 | 0368 | 0370 |
| R0288-06       | 1000 | 125 |   |     | 0378 | 0380 | 0382 | 0383 | 0386 | 0388 | 0390 | 0392 | 0394 |      |      | 0396 | 0398 | 0400 |
| R0288-06       | 1000 | 150 |   |     | 0408 | 0410 | 0412 | 0414 | 0416 | 0418 | 0420 | 0422 | 0424 |      |      | 0426 | 0428 | 0430 |
| R0288-06       | 1000 | 160 |   |     | 0438 | 0440 | 0442 | 0444 | 0446 | 0448 | 0450 | 0452 | 0454 |      |      | 0456 | 0458 | 0460 |
| R0288-06       | 1000 | 180 |   |     | 0468 | 0470 | 0472 | 0474 | 0476 | 0478 | 0480 | 0482 | 0484 |      |      | 0486 | 0488 | 0490 |
| R0288-06       | 1000 | 200 |   |     | 0498 | 0500 | 0502 | 0504 | 0506 | 0508 | 0510 | 0512 | 0514 |      |      | 0516 | 0518 | 0520 |
| R0288-06       | 1000 | 250 |   |     | 0528 | 0530 | 0532 | 0534 | 0536 | 0538 | 0540 | 0542 | 0544 |      |      | 0546 | 0548 | 0550 |
| R0288-06       | 1000 | 300 |   |     | 0558 | 0560 | 0562 | 0564 | 0566 | 0568 | 0570 | 0572 | 0574 |      |      | 0576 | 0578 | 0580 |