


Piastre pre-rettificate

Pre-finished flat steel plates



R0290

Piastra pre-rettificata - P2379
Pre-finished flat steel plate - P2379



 Colore identificativo
Colour symbol

Descrizione:

Esempio di ordinativo: **R0290-06-0001**

Materiale: 1.2379

Tolleranze L500: S +0.25 mm, B +0.4 mm, L +25 mm

Tolleranze L1030: S +0.25 mm, B +0.4 mm, L ±20 mm

Per la sezione quadrata: S e B +0.25 mm

Description:

Example of purchasing order: **R0290-06-0001**

Material: 1.2379

Tolerances L500: S +0.25 mm, B +0.4 mm, L +20 mm

Tolerances L1030: S +0.25 mm, B +0.4 mm, L ±20 mm

For square section: S and B +0.25 mm

Codice Code	L	B	S																					
			2.2	3.2	4.2	5.2	6.2	8.2	10.4	12.4	15.4	20.4	25.4	30.4	40.4	50.4	60.4	63.4	70.4	80.4	90.4	100.4	120.4	150.4
R0290-06	500	6.2					0001																	
R0290-06	500	8.2						0002																
R0290-06	500	10.3	0003	0004	0005	0006	0007	0008																
R0290-06	500	10.4							0009															
R0290-06	500	12.4								0010														
R0290-06	500	15.3	0011	0012	0013	0014	0015	0016	0017	0018														
R0290-06	500	15.4								0019														
R0290-06	500	20.3	0020	0021	0022	0023	0024	0025	0026	0027	0028													
R0290-06	500	20.4									0029													
R0290-06	500	25.3	0030	0031	0032	0033	0034	0035	0036	0037	0038	0039												
R0290-06	500	25.4									0040													
R0290-06	500	30.3	0041	0042	0043	0044	0045	0046	0047	0048	0049	0050	0051											
R0290-06	500	30.4										0052												
R0290-06	500	40.3	0053	0054	0055	0056	0057	0058	0059	0060	0061	0062	0063	0064										
R0290-06	500	40.4												0065										
R0290-06	500	50.3	0066	0067	0068	0069	0070	0071	0072	0073	0074	0075	0076	0077	0078									
R0290-06	500	50.4													0079									
R0290-06	500	60.3	0080	0081	0082	0083	0084	0085	0086	0087	0088	0089	0090	0091	0092	0093								
R0290-06	500	60.4														0094								
R0290-06	500	63.4															0095							
R0290-06	500	70.4															0096	0097	0098					
R0290-06	500	80.3	0099	0100	0101	0102	0103	0104	0105	0106	0107	0108	0109	0110	0111	0112	0113	0114	0115					
R0290-06	500	80.4																		0116				
R0290-06	500	90.4															0117	0118	0119	0120	0121			
R0290-06	500	100.3	0122	0123	0124	0125	0126	0127	0128	0129	0130	0131	0132	0133	0134	0135	0136	0137	0138	0139	0140			
R0290-06	500	100.4																				0141		
R0290-06	500	120.4																					0142	
R0290-06	500	125.3	0143	0144	0145	0146	0147	0148	0149	0150	0151	0152	0153	0154	0155	0156								
R0290-06	500	125.4															0157	0158	0159	0160	0161	0162		
R0290-06	500	150.3	0163	0164	0165	0166	0167	0168	0169	0170	0171	0172	0173	0174	0175	0176								
R0290-06	500	150.4															0177	0178	0179	0180	0181	0182		0183
R0290-06	500	160.4															0184	0185	0186	0187	0188	0189		
R0290-06	500	175.4															0190	0191	0192	0193	0194	0195		
R0290-06	500	180.4															0196	0197	0198	0199	0200	0201		
R0290-06	500	200.3	0202	0203	0204	0205	0206	0207	0208	0209	0210	0211	0212	0213	0214	0215								
R0290-06	500	200.4															0216	0217	0218	0219	0220	0221		
R0290-06	500	250.3	0222	0223	0224	0225	0226	0227	0228	0229	0230	0231	0232	0233	0234	0235								
R0290-06	500	250.4															0236	0237	0238	0239	0240	0241		
R0290-06	500	300.3	0242	0243	0244	0245	0246	0247	0248	0249	0250	0251	0252	0253	0254	0255								
R0290-06	500	300.4															0256	0257	0258	0259	0260	0261		
R0290-06	500	350.4															0262							

Piastre pre-rettificate


Pre-finished flat steel plates



R0290

Piastra pre-rettificata - P2379

Pre-finished flat steel plate - P2379



Colore identificativo
Colour symbol

Descrizione:

Esempio di ordinativo: R0290-06-0001

Materiale: 1.2379

Tolleranze L500: S +0.25 mm, B +0.4 mm, L +25 mm

Tolleranze L1030: S +0.25 mm, B +0.4 mm, L ±20 mm

Per la sezione quadrata: S e B +0.25 mm

Description:

Example of purchasing order: R0290-06-0001

Material: 1.2379

Tolerances L500: S +0.25 mm, B +0.4 mm, L +20 mm

Tolerances L1030: S +0.25 mm, B +0.4 mm, L ±20 mm

For square section: S and B +0.25 mm

Codice Code	L	B	S																											
			2.4	3.4	4.4	5.4	6.4	8.4	10.4	12.4	15.4	16.4	20.4	25.4	26.4	30.4	32.4	36.4	40.4	46.4	50.4	60.4	63.4	70.4	80.4	90.4	100.4	120.4	150.4	
R0290-06	1030	6.4					0263																							
R0290-06	1030	8.4						0264																						
R0290-06	1030	10.4	0265	0266	0267	0268	0269	0270	0271																					
R0290-06	1030	12.4								0272																				
R0290-06	1030	15.4	0273	0274	0275	0276	0277	0278	0279	0280	0281																			
R0290-06	1030	16.4									0282																			
R0290-06	1030	20.4	0283	0284	0285	0286	0287	0288	0289	0290	0291	0292	0293																	
R0290-06	1030	25.4	0294	0295	0296	0297	0298	0299	0300	0301	0302	0303	0304	0305																
R0290-06	1030	30.4	0306	0307	0308	0309	0310	0311	0312	0313	0314	0315	0316	0317		0318														
R0290-06	1030	32.4	0319	0320	0321	0322	0323	0324	0325	0326	0327	0328	0329	0330		0331	0332													
R0290-06	1030	40.4	0333	0334	0335	0336	0337	0338	0339	0340	0341	0342	0343	0344		0345	0346		0347											
R0290-06	1030	50.4	0348	0349	0350	0351	0352	0353	0354	0355	0356	0357	0358	0359		0360	0361		0362		0363									
R0290-06	1030	60.4	0364	0365	0366	0367	0368	0369	0370	0371	0372	0373	0374	0375		0376	0377		0378		0379	0380								
R0290-06	1030	63.4	0381	0382	0383	0384	0385	0386	0387	0388	0389	0390	0391	0392		0393	0394		0395		0396		0397							
R0290-06	1030	70.4	0398	0399	0400	0401	0402	0403	0404	0405	0406	0407	0408	0409		0410	0411		0412		0413	0414	0415	0416						
R0290-06	1030	80.4	0417	0418	0419	0420	0421	0422	0423	0424	0425	0426	0427	0428		0429	0430		0431		0432	0433	0434	0435	0436					
R0290-06	1030	90.4	0437	0438	0439	0440	0441	0442	0443	0444	0445	0446	0447	0448		0449	0450		0451		0452	0453	0454	0455	0456	0457				
R0290-06	1030	100.4	0458	0459	0460	0461	0462	0463	0464	0465	0466	0467	0468	0469		0470	0471		0472		0473	0474	0475	0476	0477	0478	0479			
R0290-06	1030	120.4																										0480		
R0290-06	1030	125.4	0481	0482	0483	0484	0485	0486	0487	0488	0489	0490	0491	0492		0493	0494		0495		0496	0497	0498	0499	0500	0501	0502			
R0290-06	1030	150.4	0503	0504	0505	0506	0507	0508	0509	0510	0511	0512	0513	0514		0515	0516		0517		0518	0519	0520	0521	0522	0523	0524		0525	
R0290-06	1030	156.4														0526			0527		0528									
R0290-06	1030	160.4	0529	0530	0531	0532	0533	0534	0535	0536	0537	0538	0539	0540		0541	0542		0543		0544	0545	0546	0547	0548	0549	0550			
R0290-06	1030	175.4	0551	0552	0553	0554	0555	0556	0557	0558	0559	0560	0561	0562		0563	0564		0565		0566	0567	0568	0569	0570	0571	0572			
R0290-06	1030	180.4	0573	0574	0575	0576	0577	0578	0579	0580	0581	0582	0583	0584		0585	0586		0587		0588	0589	0590	0591	0592	0593	0594			
R0290-06	1030	196.4														0595			0596		0597									
R0290-06	1030	200.4	0598	0599	0600	0601	0602	0603	0604	0605	0606	0607	0608	0609		0610	0611		0612		0613	0614	0615	0616	0617	0618	0619			
R0290-06	1030	246.4														0620			0621		0622									
R0290-06	1030	250.4	0623	0624	0625	0626	0627	0628	0629	0630	0631	0632	0633	0634		0635	0636		0637		0638	0639	0640	0641	0642	0643	0644			
R0290-06	1030	296.4														0645			0646		647									
R0290-06	1030	300.4	0648	0649	0650	0651	0652	0653	0654	0655	0656	0657	0658	0659		0660	0661		0662		0663	0664	0665	0666	0667	0668	0669			
R0290-06	1030	350.4								0670	0671	0672	0673	0674	0675		0676	0677		0678		0679	0680							
R0290-06	1030	400.4								0681	0682	0683	0684	0685	0686		0687	0688		0689		0690								